



NOTES:

1. FILL SAMPLE PIPING w/HEAVILY CHLORINATED WATER WHILE MAINS ARE BEING STERILIZED. (MIX 2 TABLESPOONS OF H.T.H. PER GALLON WATER IN SAMPLE PIPING); CONTACT TIME TO BE 30 MINUTES (minimum)
2. WATER MUST BE RUNNING FROM BALL VALVE (SLOWLY) FOR 30 MINUTES PRIOR TO SAMPLE
3. OPERATE HYDRANT FROM 6" GATE VALVE, DO NOT OPERATE FROM STEM NUT.



GreenvilleWater

2" BLOW-OFF PIPING FOR HYDRANT
(FOR SAMPLING)

REVISED: 1/26/2021